

# Spectral Compliance Assessment – 2% Blue-Light Standard

**Fixture ID:** SL\_083\_02°\_3001K

**Location:** 48 Nonohe Pl, Paia, HI 96779

**Date / Time:** December 4, 2025, 19:35 HST

**Measurement Mode:** Ambient, direct view of emitting aperture

## 1. Measurement Overview

A field spectral measurement was conducted *in situ* of a down-facing exterior light fixture. The spectrometer was positioned directly below the emitting aperture and aligned on-axis with the primary luminous output. The photographic record documents the measurement geometry, GPS location, and operating conditions, establishing provenance and traceability. The geometry is appropriate for characterizing emitted spectral content independent of surface reflections.

## 2. Correlated Color Temperature (CCT)

The measured Correlated Color Temperature (CCT) of the fixture is 3001 K, placing it in the nominal 'warm white' category. However, CCT alone is not a reliable indicator of blue-light compliance, as phosphor-converted LEDs can maintain low CCT values while emitting significant short-wavelength energy.

## 3. Spectral Power Distribution and Blue Fraction

Analysis of the measured Spectral Power Distribution (SPD) shows a pronounced short-wavelength component characteristic of phosphor-converted white LEDs, including a distinct blue pump contribution in the ~440–460 nm region. Integration of the SPD indicates that 14.75% of the total emitted radiant power lies below 500 nm.

## 4. Compliance Evaluation Against 2% Blue Standard

The applicable lighting ordinance limits blue-light emissions to no more than 2% of total spectral output. The measured blue fraction of 14.75% exceeds the allowable limit by a factor of approximately 7.4x. This exceedance is substantial and cannot be attributed to measurement uncertainty.

## 5. Conclusion

Based on direct field measurement and quantitative spectral analysis, the evaluated fixture does not meet the 2% blue-light emission standard applicable to the measurement location. Despite its nominally warm CCT, the fixture emits a high fraction of short-wavelength light and is therefore non-compliant under the ordinance.

ALTITUDE  
22.1 M

20°N

COURSE N 0° GPS




LAT 20°54'39.853"N THURSDAY 12.04.2025

LONG 156°24'9.841"W LOCAL TIME 19:35:42

48 Nonohe Pl, Paia, HI 96779, USA


SL\_083\_02°\_3001K

% BLUE = 14.7467



SL\_083\_02°\_3001K

% BLUE = 14.7467



Date Saved	#####	3	4	5
Title	SL_083_02-∞_3001K			
% BLUE	14.7467			
Measuring Mode	Ambient			
Viewing Angle [∞]	2			
CCT [K]	3001			
,äøuv	-0.0025			
Illuminance [lx]	4420			
Peak Wavelength [nm]	604			
Tristimulus Value X	4827.9407			
Tristimulus Value Y	4419.8994			
Tristimulus Value Z	1893.9331			
CIE1931 x	0.4333			
CIE1931 y	0.3967			
CIE1931 z	0.17			
CIE1976 u'	0.2514			
CIE1976 v'	0.5179			
Dominant Wavelength [nm]	584			
Purity [%]	49.1			
PPFD [umolm,Å-≤s,Å-π]	63.3			
CRI Ra	83.1			
CRI R1	82.5			
CRI R2	93.2			
CRI R3	94.5			
CRI R4	80.3			
CRI R5	82.9			
CRI R6	91.6			
CRI R7	81.3			
CRI R8	58.8			
CRI R9	9.4			
CRI R10	84			
CRI R11	79.7			
CRI R12	74.7			
CRI R13	85.3			
CRI R14	97.9			
CRI R15	75.4			
TM-30 Rf	85			
TM-30 Rg	96			
SSI <sub>t</sub>	75			
SSI <sub>d</sub>	52			
SSI <sub>1</sub>	---			
SSI <sub>2</sub>	---			

TLCI	69
TLMF	---

Spectral Data 380[nm]	0.00112528
Spectral Data 385[nm]	0.00112886
Spectral Data 390[nm]	0.0011199
Spectral Data 395[nm]	0.00087103
Spectral Data 400[nm]	0.00066128
Spectral Data 405[nm]	0.00077681
Spectral Data 410[nm]	0.00111995
Spectral Data 415[nm]	0.00146733
Spectral Data 420[nm]	0.00213522
Spectral Data 425[nm]	0.00364564
Spectral Data 430[nm]	0.00636494
Spectral Data 435[nm]	0.01120753
Spectral Data 440[nm]	0.01945694
Spectral Data 445[nm]	0.03128082
Spectral Data 450[nm]	0.04272569
Spectral Data 455[nm]	0.04734564
Spectral Data 460[nm]	0.04347688
Spectral Data 465[nm]	0.03572851
Spectral Data 470[nm]	0.02844937
Spectral Data 475[nm]	0.0232994
Spectral Data 480[nm]	0.02057646
Spectral Data 485[nm]	0.02013977
Spectral Data 490[nm]	0.02179793
Spectral Data 495[nm]	0.02495864
Spectral Data 500[nm]	0.02872834
Spectral Data 505[nm]	0.03225314
Spectral Data 510[nm]	0.03528169
Spectral Data 515[nm]	0.03783914
Spectral Data 520[nm]	0.04020052
Spectral Data 525[nm]	0.04283485
Spectral Data 530[nm]	0.04554234
Spectral Data 535[nm]	0.04765728
Spectral Data 540[nm]	0.04900963
Spectral Data 545[nm]	0.0507952
Spectral Data 550[nm]	0.05373127
Spectral Data 555[nm]	0.05703531
Spectral Data 560[nm]	0.06069258
Spectral Data 565[nm]	0.0648323
Spectral Data 570[nm]	0.0695156
Spectral Data 575[nm]	0.07422163

Spectral Data 580[nm]	0.07867641
Spectral Data 585[nm]	0.08288808
Spectral Data 590[nm]	0.08658186
Spectral Data 595[nm]	0.08946724
Spectral Data 600[nm]	0.09121548
Spectral Data 605[nm]	0.09161823
Spectral Data 610[nm]	0.0907187
Spectral Data 615[nm]	0.08842272
Spectral Data 620[nm]	0.08501987
Spectral Data 625[nm]	0.08084308
Spectral Data 630[nm]	0.07605105
Spectral Data 635[nm]	0.07055432
Spectral Data 640[nm]	0.06470557
Spectral Data 645[nm]	0.05872829
Spectral Data 650[nm]	0.05276205
Spectral Data 655[nm]	0.04686378
Spectral Data 660[nm]	0.04125644
Spectral Data 665[nm]	0.0360448
Spectral Data 670[nm]	0.03140731
Spectral Data 675[nm]	0.02711145
Spectral Data 680[nm]	0.0231602
Spectral Data 685[nm]	0.01980242
Spectral Data 690[nm]	0.01706563
Spectral Data 695[nm]	0.01462069
Spectral Data 700[nm]	0.01246165
Spectral Data 705[nm]	0.01060418
Spectral Data 710[nm]	0.0090091
Spectral Data 715[nm]	0.00780011
Spectral Data 720[nm]	0.00642046
Spectral Data 725[nm]	0.00512083
Spectral Data 730[nm]	0.00460937
Spectral Data 735[nm]	0.00389058
Spectral Data 740[nm]	0.00278036
Spectral Data 745[nm]	0.00207938
Spectral Data 750[nm]	0.00188659
Spectral Data 755[nm]	0.00154188
Spectral Data 760[nm]	0.00073203
Spectral Data 765[nm]	0.00133613
Spectral Data 770[nm]	0.00043231
Spectral Data 775[nm]	6.12E-05
Spectral Data 780[nm]	0.00034861
Spectral Data 380[nm]	0.00121393

Spectral Data 381[nm]	0.00113566
Spectral Data 382[nm]	0.0010786
Spectral Data 383[nm]	0.00106531
Spectral Data 384[nm]	0.00108765
Spectral Data 385[nm]	0.00112712
Spectral Data 386[nm]	0.0011652
Spectral Data 387[nm]	0.00118576
Spectral Data 388[nm]	0.00118679
Spectral Data 389[nm]	0.00117142
Spectral Data 390[nm]	0.00114284
Spectral Data 391[nm]	0.00110397
Spectral Data 392[nm]	0.00105633
Spectral Data 393[nm]	0.00100089
Spectral Data 394[nm]	0.00093858
Spectral Data 395[nm]	0.00087081
Spectral Data 396[nm]	0.00080214
Spectral Data 397[nm]	0.0007385
Spectral Data 398[nm]	0.00068584
Spectral Data 399[nm]	0.00064952
Spectral Data 400[nm]	0.00063042
Spectral Data 401[nm]	0.00062739
Spectral Data 402[nm]	0.00063923
Spectral Data 403[nm]	0.00066481
Spectral Data 404[nm]	0.00070336
Spectral Data 405[nm]	0.0007543
Spectral Data 406[nm]	0.00081704
Spectral Data 407[nm]	0.00089068
Spectral Data 408[nm]	0.00097136
Spectral Data 409[nm]	0.00105358
Spectral Data 410[nm]	0.00113184
Spectral Data 411[nm]	0.0012012
Spectral Data 412[nm]	0.00126265
Spectral Data 413[nm]	0.00132065
Spectral Data 414[nm]	0.0013797
Spectral Data 415[nm]	0.00144441
Spectral Data 416[nm]	0.00152049
Spectral Data 417[nm]	0.00161436
Spectral Data 418[nm]	0.00173245
Spectral Data 419[nm]	0.001881
Spectral Data 420[nm]	0.0020638
Spectral Data 421[nm]	0.00228294
Spectral Data 422[nm]	0.00254048
Spectral Data 423[nm]	0.00283846

Spectral Data 424[nm]	0.00317803
Spectral Data 425[nm]	0.00355967
Spectral Data 426[nm]	0.00398389
Spectral Data 427[nm]	0.00445147
Spectral Data 428[nm]	0.00496905
Spectral Data 429[nm]	0.00554784
Spectral Data 430[nm]	0.00619911
Spectral Data 431[nm]	0.00693412
Spectral Data 432[nm]	0.00776395
Spectral Data 433[nm]	0.00869951
Spectral Data 434[nm]	0.00975172
Spectral Data 435[nm]	0.01093086
Spectral Data 436[nm]	0.01224826
Spectral Data 437[nm]	0.01371604
Spectral Data 438[nm]	0.01534577
Spectral Data 439[nm]	0.01714837
Spectral Data 440[nm]	0.01912637
Spectral Data 441[nm]	0.02127311
Spectral Data 442[nm]	0.02358105
Spectral Data 443[nm]	0.02604223
Spectral Data 444[nm]	0.0286277
Spectral Data 445[nm]	0.0312783
Spectral Data 446[nm]	0.03393249
Spectral Data 447[nm]	0.03652855
Spectral Data 448[nm]	0.03900381
Spectral Data 449[nm]	0.0412947
Spectral Data 450[nm]	0.04333703
Spectral Data 451[nm]	0.04506676
Spectral Data 452[nm]	0.04643249
Spectral Data 453[nm]	0.04741144
Spectral Data 454[nm]	0.04798589
Spectral Data 455[nm]	0.04813809
Spectral Data 456[nm]	0.0478671
Spectral Data 457[nm]	0.04722777
Spectral Data 458[nm]	0.04628585
Spectral Data 459[nm]	0.04510713
Spectral Data 460[nm]	0.04375269
Spectral Data 461[nm]	0.04226345
Spectral Data 462[nm]	0.04067506
Spectral Data 463[nm]	0.03902315
Spectral Data 464[nm]	0.03734282
Spectral Data 465[nm]	0.03566601
Spectral Data 466[nm]	0.03402355

Spectral Data 467[nm]	0.03244626
Spectral Data 468[nm]	0.0309621
Spectral Data 469[nm]	0.02957564
Spectral Data 470[nm]	0.02828041
Spectral Data 471[nm]	0.02706996
Spectral Data 472[nm]	0.02593857
Spectral Data 473[nm]	0.02489048
Spectral Data 474[nm]	0.02393582
Spectral Data 475[nm]	0.02308472
Spectral Data 476[nm]	0.02234665
Spectral Data 477[nm]	0.02172021
Spectral Data 478[nm]	0.0211955
Spectral Data 479[nm]	0.02076235
Spectral Data 480[nm]	0.02041102
Spectral Data 481[nm]	0.02013937
Spectral Data 482[nm]	0.01995307
Spectral Data 483[nm]	0.01985825
Spectral Data 484[nm]	0.01986081
Spectral Data 485[nm]	0.01996101
Spectral Data 486[nm]	0.02015177
Spectral Data 487[nm]	0.02042543
Spectral Data 488[nm]	0.02077441
Spectral Data 489[nm]	0.02119251
Spectral Data 490[nm]	0.0216758
Spectral Data 491[nm]	0.02222067
Spectral Data 492[nm]	0.02282346
Spectral Data 493[nm]	0.02347877
Spectral Data 494[nm]	0.02417733
Spectral Data 495[nm]	0.02490939
Spectral Data 496[nm]	0.02566517
Spectral Data 497[nm]	0.02643539
Spectral Data 498[nm]	0.0272122
Spectral Data 499[nm]	0.02798797
Spectral Data 500[nm]	0.02875509
Spectral Data 501[nm]	0.02950677
Spectral Data 502[nm]	0.03023962
Spectral Data 503[nm]	0.03095099
Spectral Data 504[nm]	0.03163828
Spectral Data 505[nm]	0.03229967
Spectral Data 506[nm]	0.03293756
Spectral Data 507[nm]	0.03355564
Spectral Data 508[nm]	0.03415763
Spectral Data 509[nm]	0.03474655

Spectral Data 510[nm]	0.03532048
Spectral Data 511[nm]	0.03587543
Spectral Data 512[nm]	0.03640742
Spectral Data 513[nm]	0.03691308
Spectral Data 514[nm]	0.03739517
Spectral Data 515[nm]	0.03785988
Spectral Data 516[nm]	0.03831343
Spectral Data 517[nm]	0.03876209
Spectral Data 518[nm]	0.03921335
Spectral Data 519[nm]	0.03967558
Spectral Data 520[nm]	0.04015709
Spectral Data 521[nm]	0.04066575
Spectral Data 522[nm]	0.0411998
Spectral Data 523[nm]	0.04174864
Spectral Data 524[nm]	0.04230129
Spectral Data 525[nm]	0.04284706
Spectral Data 526[nm]	0.04338369
Spectral Data 527[nm]	0.04391885
Spectral Data 528[nm]	0.04446073
Spectral Data 529[nm]	0.0450173
Spectral Data 530[nm]	0.04558333
Spectral Data 531[nm]	0.04613345
Spectral Data 532[nm]	0.04664064
Spectral Data 533[nm]	0.04707797
Spectral Data 534[nm]	0.0474342
Spectral Data 535[nm]	0.04772938
Spectral Data 536[nm]	0.04798727
Spectral Data 537[nm]	0.04823164
Spectral Data 538[nm]	0.04848015
Spectral Data 539[nm]	0.04873489
Spectral Data 540[nm]	0.04899545
Spectral Data 541[nm]	0.04926143
Spectral Data 542[nm]	0.04953712
Spectral Data 543[nm]	0.04984288
Spectral Data 544[nm]	0.05020253
Spectral Data 545[nm]	0.05063993
Spectral Data 546[nm]	0.05117143
Spectral Data 547[nm]	0.05177714
Spectral Data 548[nm]	0.05242698
Spectral Data 549[nm]	0.05309087
Spectral Data 550[nm]	0.05374187
Spectral Data 551[nm]	0.05437884
Spectral Data 552[nm]	0.05501271

Spectral Data 553[nm]	0.05565446
Spectral Data 554[nm]	0.05631464
Spectral Data 555[nm]	0.05699668
Spectral Data 556[nm]	0.05769807
Spectral Data 557[nm]	0.05841612
Spectral Data 558[nm]	0.05914818
Spectral Data 559[nm]	0.05989355
Spectral Data 560[nm]	0.06065427
Spectral Data 561[nm]	0.06143259
Spectral Data 562[nm]	0.06223072
Spectral Data 563[nm]	0.06305107
Spectral Data 564[nm]	0.06389652
Spectral Data 565[nm]	0.06476999
Spectral Data 566[nm]	0.0656744
Spectral Data 567[nm]	0.06661067
Spectral Data 568[nm]	0.06757083
Spectral Data 569[nm]	0.06854437
Spectral Data 570[nm]	0.06952079
Spectral Data 571[nm]	0.07049027
Spectral Data 572[nm]	0.07144866
Spectral Data 573[nm]	0.07239464
Spectral Data 574[nm]	0.07332692
Spectral Data 575[nm]	0.07424432
Spectral Data 576[nm]	0.07514785
Spectral Data 577[nm]	0.07604037
Spectral Data 578[nm]	0.07692478
Spectral Data 579[nm]	0.07780395
Spectral Data 580[nm]	0.07867898
Spectral Data 581[nm]	0.07954836
Spectral Data 582[nm]	0.08041033
Spectral Data 583[nm]	0.08126317
Spectral Data 584[nm]	0.08210429
Spectral Data 585[nm]	0.0829288
Spectral Data 586[nm]	0.08373149
Spectral Data 587[nm]	0.08450714
Spectral Data 588[nm]	0.08525128
Spectral Data 589[nm]	0.0859635
Spectral Data 590[nm]	0.08664447
Spectral Data 591[nm]	0.08729486
Spectral Data 592[nm]	0.08791497
Spectral Data 593[nm]	0.08850183
Spectral Data 594[nm]	0.08905078
Spectral Data 595[nm]	0.08955713

Spectral Data 596[nm]	0.09001634
Spectral Data 597[nm]	0.09042502
Spectral Data 598[nm]	0.09078077
Spectral Data 599[nm]	0.09108128
Spectral Data 600[nm]	0.09132424
Spectral Data 601[nm]	0.09150926
Spectral Data 602[nm]	0.09163872
Spectral Data 603[nm]	0.09171519
Spectral Data 604[nm]	0.09174123
Spectral Data 605[nm]	0.0917184
Spectral Data 606[nm]	0.09164579
Spectral Data 607[nm]	0.09152214
Spectral Data 608[nm]	0.09134619
Spectral Data 609[nm]	0.0911165
Spectral Data 610[nm]	0.09083083
Spectral Data 611[nm]	0.09048677
Spectral Data 612[nm]	0.09008184
Spectral Data 613[nm]	0.08961449
Spectral Data 614[nm]	0.08908936
Spectral Data 615[nm]	0.08851399
Spectral Data 616[nm]	0.08789599
Spectral Data 617[nm]	0.08724261
Spectral Data 618[nm]	0.08655679
Spectral Data 619[nm]	0.085838
Spectral Data 620[nm]	0.08508562
Spectral Data 621[nm]	0.08429908
Spectral Data 622[nm]	0.08348031
Spectral Data 623[nm]	0.0826345
Spectral Data 624[nm]	0.08176708
Spectral Data 625[nm]	0.08088342
Spectral Data 626[nm]	0.07998534
Spectral Data 627[nm]	0.07906678
Spectral Data 628[nm]	0.07812071
Spectral Data 629[nm]	0.07714006
Spectral Data 630[nm]	0.07611993
Spectral Data 631[nm]	0.07506339
Spectral Data 632[nm]	0.07397539
Spectral Data 633[nm]	0.07286093
Spectral Data 634[nm]	0.07172497
Spectral Data 635[nm]	0.07057252
Spectral Data 636[nm]	0.0694086
Spectral Data 637[nm]	0.06823823
Spectral Data 638[nm]	0.067066

Spectral Data 639[nm]	0.06589188
Spectral Data 640[nm]	0.06471305
Spectral Data 641[nm]	0.06352664
Spectral Data 642[nm]	0.06233003
Spectral Data 643[nm]	0.06112519
Spectral Data 644[nm]	0.05991806
Spectral Data 645[nm]	0.05871473
Spectral Data 646[nm]	0.05752115
Spectral Data 647[nm]	0.05633744
Spectral Data 648[nm]	0.0551564
Spectral Data 649[nm]	0.05397033
Spectral Data 650[nm]	0.05277162
Spectral Data 651[nm]	0.0515595
Spectral Data 652[nm]	0.05034577
Spectral Data 653[nm]	0.04914359
Spectral Data 654[nm]	0.04796609
Spectral Data 655[nm]	0.04682048
Spectral Data 656[nm]	0.04569769
Spectral Data 657[nm]	0.04458594
Spectral Data 658[nm]	0.04347345
Spectral Data 659[nm]	0.04235236
Spectral Data 660[nm]	0.04123092
Spectral Data 661[nm]	0.04012158
Spectral Data 662[nm]	0.03903677
Spectral Data 663[nm]	0.03798721
Spectral Data 664[nm]	0.03697295
Spectral Data 665[nm]	0.03598987
Spectral Data 666[nm]	0.03503383
Spectral Data 667[nm]	0.03410068
Spectral Data 668[nm]	0.03318583
Spectral Data 669[nm]	0.03228441
Spectral Data 670[nm]	0.03139159
Spectral Data 671[nm]	0.0305033
Spectral Data 672[nm]	0.02962156
Spectral Data 673[nm]	0.02875237
Spectral Data 674[nm]	0.0279019
Spectral Data 675[nm]	0.02707543
Spectral Data 676[nm]	0.02626976
Spectral Data 677[nm]	0.02547675
Spectral Data 678[nm]	0.02468823
Spectral Data 679[nm]	0.02389766
Spectral Data 680[nm]	0.02311348
Spectral Data 681[nm]	0.02235202

Spectral Data 682[nm]	0.02162969
Spectral Data 683[nm]	0.02096061
Spectral Data 684[nm]	0.02034032
Spectral Data 685[nm]	0.01975532
Spectral Data 686[nm]	0.01919204
Spectral Data 687[nm]	0.01863832
Spectral Data 688[nm]	0.0180925
Spectral Data 689[nm]	0.01755765
Spectral Data 690[nm]	0.01703683
Spectral Data 691[nm]	0.01653236
Spectral Data 692[nm]	0.01604162
Spectral Data 693[nm]	0.0155599
Spectral Data 694[nm]	0.0150825
Spectral Data 695[nm]	0.014606
Spectral Data 696[nm]	0.01413476
Spectral Data 697[nm]	0.01367608
Spectral Data 698[nm]	0.01323728
Spectral Data 699[nm]	0.01282399
Spectral Data 700[nm]	0.01243248
Spectral Data 701[nm]	0.01205581
Spectral Data 702[nm]	0.011687
Spectral Data 703[nm]	0.01132022
Spectral Data 704[nm]	0.01095522
Spectral Data 705[nm]	0.01059347
Spectral Data 706[nm]	0.01023646
Spectral Data 707[nm]	0.0098866
Spectral Data 708[nm]	0.00955071
Spectral Data 709[nm]	0.00923682
Spectral Data 710[nm]	0.00895296
Spectral Data 711[nm]	0.00870373
Spectral Data 712[nm]	0.00847964
Spectral Data 713[nm]	0.00826754
Spectral Data 714[nm]	0.00805432
Spectral Data 715[nm]	0.00782876
Spectral Data 716[nm]	0.00758691
Spectral Data 717[nm]	0.00732654
Spectral Data 718[nm]	0.0070454
Spectral Data 719[nm]	0.00674342
Spectral Data 720[nm]	0.00642797
Spectral Data 721[nm]	0.00610804
Spectral Data 722[nm]	0.00579261
Spectral Data 723[nm]	0.00549248
Spectral Data 724[nm]	0.00522415

Spectral Data 725[nm]	0.00500527
Spectral Data 726[nm]	0.00485347
Spectral Data 727[nm]	0.00477465
Spectral Data 728[nm]	0.00474093
Spectral Data 729[nm]	0.00471833
Spectral Data 730[nm]	0.00467292
Spectral Data 731[nm]	0.00458171
Spectral Data 732[nm]	0.00445071
Spectral Data 733[nm]	0.00429066
Spectral Data 734[nm]	0.00411229
Spectral Data 735[nm]	0.00392239
Spectral Data 736[nm]	0.00371825
Spectral Data 737[nm]	0.00349575
Spectral Data 738[nm]	0.00325076
Spectral Data 739[nm]	0.00298731
Spectral Data 740[nm]	0.00272745
Spectral Data 741[nm]	0.0024957
Spectral Data 742[nm]	0.00231647
Spectral Data 743[nm]	0.00219964
Spectral Data 744[nm]	0.00212526
Spectral Data 745[nm]	0.00206969
Spectral Data 746[nm]	0.00200946
Spectral Data 747[nm]	0.00193577
Spectral Data 748[nm]	0.00186761
Spectral Data 749[nm]	0.00182703
Spectral Data 750[nm]	0.00183581
Spectral Data 751[nm]	0.00189128
Spectral Data 752[nm]	0.00194817
Spectral Data 753[nm]	0.00195697
Spectral Data 754[nm]	0.00186864
Spectral Data 755[nm]	0.00166818
Spectral Data 756[nm]	0.00139518
Spectral Data 757[nm]	0.00109416
Spectral Data 758[nm]	0.00080961
Spectral Data 759[nm]	0.00058533
Spectral Data 760[nm]	0.00046399
Spectral Data 761[nm]	0.00048821
Spectral Data 762[nm]	0.00069893
Spectral Data 763[nm]	0.00106381
Spectral Data 764[nm]	0.00145023
Spectral Data 765[nm]	0.00171832
Spectral Data 766[nm]	0.00173122
Spectral Data 767[nm]	0.00146348

Spectral Data 768[nm]	0.00103058
Spectral Data 769[nm]	0.00055708
Spectral Data 770[nm]	0.00016541
Spectral Data 771[nm]	0
Spectral Data 772[nm]	0
Spectral Data 773[nm]	0
Spectral Data 774[nm]	0
Spectral Data 775[nm]	0
Spectral Data 776[nm]	1.56E-05
Spectral Data 777[nm]	0.00015811
Spectral Data 778[nm]	0.00029369
Spectral Data 779[nm]	0.00040515
Spectral Data 780[nm]	0.00047827

TM-30 Color Vector Graphic Reference Ill Reference Ill Measured Ill Measured Illuminant y